


Flir Cloud Computer App Setup

App Setup


NOTE: FLIR Cloud™ Client is a central management software that allows you to view and manage multiple FLIR security systems on a PC or Mac. It includes support for FLIR Cloud™ Services, allowing a simple, secure connection to compatible systems over the Internet with no network configuration required.

Log into the Client Software using the Client Software user name (default: admin) and password (admin)



To connect to your system using FLIR Cloud™ Services:

1. Click  and then click .
2. Click **Add Device**




3. Enter the following:

- 3.1. Device Name: Choose a name for your system of your choice.
- 3.2. Device ID: Manually enter the Device ID printed on the product label.
- 3.3. Client Port: Enter the system's Client Port.
- 3.4. User Name: Enter the system's User Name.
- 3.5. Password: Enter the system's Password.

6. Click  then .

7. Click and drag Default Group to the display window to open your cameras in live view



Congratulations! You can now connect over the Internet to view and playback video on your computer.